



USB
TO
HOST

URI



XMTR

RCVR

E1
ANTENNA

E2
ANTENNA

NOTE:
RIGHT OUTPUT HOOKUP SHOWN.
FOR LEFT OUTPUT JUMPER PINS 22 AND 24,
AND LEAVE PIN 23 UNCONNECTED.

◀◀ +12VDC
◀◀ DC RETURN

This schematic is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.